XANADU PROJECTIONS: TROUBLESHOOTING GUIDE

TABLE OF CONTENTS:

Blue Projection Screens "No Signal	p2-6
Projectors Will Not Turn On	7-8
Computer Will Not Turn On	p 9-12
Computer Screens Are Not Getting Signal "No Signal"	p 13-16
Cues Do Not Display Correctly	p 17-21

PROBLEM SOLUTION PHOTO REFERENCE


Blue

Projection

Screens

"No Signal"

- 1) Check that ALL CAT 5 Connections Are Securely Plugged into:
 - a. Video Extenders
 - b. White Boxes in Booth
 - i. (There are Two Boxes Behind the Computer Screens)
 - 1. Labeled "#1" and "#4"
- 2) Check that ALL VGA Connections are Securely Plugged into:
 - a. Video Extenders
 - b. Projectors
 - c. Back of Computer
 - d. Back of Computer Screens
- 3) Check that ALL VIDEO EXTENDERS are Plugged into Power Strip and that the Green and Yellow LED's on the Top of the Box are LIT



VIDEO EXTENDERS

PROBLEM SOLUTION PHOTO REFERENCE Blue Projection Screens "No Signal" (CONT'D) WHITE BOXES IN BOOTH

PROBLEM SOLUTION PHOTO REFERENCE Blue Projection Screens "No Signal" (CONT'D) 1 = POWER **BACK OF COMPUTER SCREENS**

PROBLEM SOLUTION PHOTO REFERENCE Blue Projection Screens "No Signal" (CONT'D) **BACK OF COMPUTER**

PROBLEM	SOLUTION	PHOTO REFERENCE
Blue		
Projection		
Screens		
"No Signal"		
(CONT'D)		
		1 = VGA 2 = POWER
		BACK OF PROJECTOR

PROBLEM	SOLUTION	PHOTO REFERENCE
Projectors	 Check that ALL Power Cables are Securely Plugged into: 	
Will Not	a. Back of Projectors	
Turn On	b. Power Stripsi. Make Sure Power Strips are Turned ON	
	i. Wake Sure Fower Strips are Further ON	
	2) BENQ 1 & 2 (SMALL POJECTORS) (1st BEAM):	
	a. Use BenQ Remote to Turn them ON	
	b. If they do not Turn on:	
	i. GO UP to 1 st BEAM:	
	1. Check Power:a. Make sure projectors	
	are Plugged into Power	
	Strips	
	b. Make Sure Power Cable	
	is Securely Plugged into	
	the Back of the	
	Projector c. Make sure Power Strips	
	are ON	

SOLUTION PROBLEM PHOTO REFERENCE 3) MITSUBISHI (BIG PROJECTOR) (BOOTH): Projectors a. Make Sure Computer is ON Will Not b. Make Sure that Lighting Console is ON Turn On c. PRESS Power Button on the Back i. If it Still Will Not turn On Check the Lights on the Front of The Projector: (CONT'D) 1. If the Green Lights on the Front Are Flashing You need to Wait for it to Cool Down 2. After the Lights Stop Flashing, If it Does Not Turn ON by Itself, **PRESS the Power Button Again** 1 = POWER CABLE (You Should See It LAMP ON) 2 = POWER BUTTON **BACK OF MITSUBISHI PROJECTOR**

SOLUTION PROBLEM PHOTO REFERENCE 1) Check that ALL Power Cables are Securely Plugged into: Computer a. Back of Computer Will Not b. Back of Each Computer Screen Turn On c. Power Strips i. Make Sure Power Strips are Turned ON 2) Make Sure Computer is ON a. PRESS Power Button on Front of Computer 3) Make Sure Screens are Turned On a. Press Black Power Button on the Bottom Right Front of Each Screen 1 = POWER BUTTON **POWER STRIP BEHIND COMPUTER**

PROBLEM	SOLUTION	PHOTO REFERENCE
Computer		
Will Not		
Turn On		
(CONT'D)		1 = POWER 2 = VGA
		BACK OF COMPUTER SCREENS


PROBLEM	SOLUTION	PHOTO REFERENCE
Computer		
Will Not		
Turn On		
(CONT'D)		
		1 = POWER BUTTON
		SCREEN FRONT

PROBLEM SOLUTION PHOTO REFERENCE Computer Will Not Turn On (CONT'D)

PROBLEM SOLUTION PHOTO REFERENCE

Computer Screens Are Not Getting Signal "No Signal"

- Check that ALL CAT 5 Connections Are Securely Plugged into:
 - a. Video Extenders
 - b. White Boxes in Booth
 - i. (There are Two Boxes Behind the Computer Screens)
 - 1. Labeled "#1" and "#4"
- 2) Check that ALL VGA Connections are Securely Plugged into:
 - a. Video Extenders
 - b. Back of Computer
 - c. Back of Computer Screens
- 3) Check that ALL VIDEO EXTENDERS are Plugged into Power Strip and that the Green and Yellow LED's on the Top of the Box are LIT



VIDEO EXTENDERS

PROBLEM	SOLUTION	PHOTO REFERENCE
Computer		
Screens Are		
Not Getting		
Signal		
"No Signal" (CONT'D)		2
		1 - CAT 5 2 - WHITE BOX
		WHITE BOXES IN BOOTH

PROBLEM	SOLUTION	PHOTO REFERENCE
Computer		
Screens Are		
Not Getting		
Signal		
"No Signal"		
(CONT'D)		1 = POWER 2 = VGA BACK OF COMPUTER SCREENS


PROBLEM	SOLUTION	PHOTO REFERENCE
Computer		
Screens Are		
Not Getting		
Signal		
"No Signal"		
(CONT'D)		1 = VGA SCREEN 1 2 = VGA SCREEN 2 3 = VGA SCREEN 3 4 = VGA SCREEN 4


3. SCREEN 3 = VE175b


4. SCREEN 4 = DELL 1704 FPV

SOLUTION PROBLEM PHOTO REFERENCE 1) Check that the Screens are Properly Arranged: Cues Do Not a. Select "Finder" Display b. Select "System Preferences" Correctly offware Undate c. Select "Displays" App Store d. Select "Arrangement" i. The Screens Should Be In order from Left to Right: (Click Each Blue Box - A Force Quit Finder Red Line Should Appear Around the Restart Appropriate Screen) Log Out Administration... 1. SCREEN 3 (should have a white bar above it to indicate the Finder) 2. SCREEN 2 **SELECT SYSTEM PREFERENCES** 3. SCREEN 1 4. SCREEN 4 2) Check that the Patch in QLab is Correct: a. Click the "Preferences" Button at the top Right Corner of the QLab Screen (Looks like a Light Switch) b. Select "Video" Tab on the Left Side of the Screen c. If patch is not correct: i. Draw Lines from the Appropriate Screen Numbers to the Appropriate Screen using Computer Mouse 1 = SELECT DISPLAYS 1. SCREEN 1 = VGA DISPLAY 2. SCREEN 2 = DELL 1702 FP

SELECT DISPLAYS







PROBLEM	SOLUTION	PHOTO REFERENCE
Cues Do Not		
Display Correctly		
Correctly		
(CONT'D)		1 * SCREEN 1 (BENQ 1) 2 * SCREEN 2 (MITSUBISHI) 3 * SCREEN 3 (QLAB)
		4 = SCREEN 4 (BEN Q 2)
		COMPUTER SCREEN ORDER